



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Canon	Digital IXUS 40	x					x				x				
Canon	Digital IXUS 50	x					x				x				
Canon	Digital IXUS 55	x					x				x				
Canon	Digital IXUS 60	x					x					x			
Canon	Digital IXUS 65	x					x					x			
Canon	Digital IXUS 700				x				x				x		
Canon	Digital IXUS 750				x				x				x		
Canon	Digital IXUS 800 IS				x				x				x		
Canon	Digital IXUS I zoom		x				x				x				
Canon	Digital IXUS wireless			x				x			x				
Canon	EOS-350D														
Canon	EOS-400D														
Canon	IXUS 850 IS				x				x				x		
Canon	IXUS 900 Ti				x				x					x	
Canon	IXUS i7		x					x			x				
Canon	Powershot A420					x									
Canon	Powershot A430					x									
Canon	Powershot A520					x				x					
Canon	Powershot A530					x									
Canon	Powershot A540					x									
Canon	Powershot A610					x									
Canon	Powershot A620					x									
Canon	Powershot A630					x									
Canon	Powershot A640					x									
Canon	Powershot A700					x									
Canon	Powershot A710 IS					x									
Canon	Powershot A85					x					x				x
Canon	Powershot A95					x					x				x
Canon	Powershot G6														
Canon	Powershot G7														
Canon	Powershot Pro1														



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Canon	Powershot S2 IS														
Canon	Powershot S3 IS														
Canon	Powershot S500	x						x			x				
Canon	Powershot S60					x			x						
Canon	Powershot S70					x			x						
Canon	Powershot S80					x			x						
Canon	Powershot SD30		x				x				x				
Canon	Powershot SD400	x					x				x				
Canon	Powershot SD450	x					x				x				
Canon	Powershot SD500				x				x				x		
Canon	Powershot SD550				x				x				x		
Canon	Powershot SD600	x						x				x			
Canon	Powershot SD630	x						x					x		
Canon	Powershot SD700				x			x					x		
Canon	SD430 wireless				x			x					x		
Casio	Exilim card EX-S600	x						x				x			
Casio	Exilim card EX-S600D	x						x				x			
Casio	Exilim card EX-S770	x							x				x		
Casio	Exilim EX-P505														
Casio	Exilim EX-P600					x									
Casio	Exilim EX-P700					x									
Casio	Exilim EX-S500	x						x					x		
Casio	Exilim EX-Z10				x				x						x
Casio	Exilim EX-Z1000			x					x			x			
Casio	Exilim EX-Z120				x				x					x	
Casio	Exilim EX-Z40	x							x			x			
Casio	Exilim EX-Z5	x							x			x			
Casio	Exilim EX-Z500	x							x				x		
Casio	Exilim EX-Z500BK	x							x					x	
Casio	Exilim EX-Z57	x							x					x	
Casio	Exilim EX-Z60				x				x					x	



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Casio	Exilim EX-Z600	x						x				x			
Casio	Exilim EX-Z70	x							x				x		
Casio	Exilim EX-Z700	x						x				x			
Casio	Exilim EX-Z750	x							x			x			
Casio	Exilim EX-Z850				x				x				x		
Casio	QV-R41				x				x						x
Casio	QV-R51				x				x						x
Casio	QV-R61				x				x						x
Fujifilm	A700				x					x					x
Fujifilm	Finepix A340					x			x						x
Fujifilm	Finepix A345			x						x					x
Fujifilm	Finepix A350				x				x					x	
Fujifilm	Finepix A400				x				x					x	
Fujifilm	Finepix A500				x				x					x	
Fujifilm	Finepix A510				x				x					x	
Fujifilm	Finepix A600				x				x				x		
Fujifilm	Finepix E500					x				x			x		
Fujifilm	Finepix E510					x				x			x		
Fujifilm	Finepix E550					x				x					x
Fujifilm	Finepix E900					x				x					x
Fujifilm	Finepix F10				x				x				x		
Fujifilm	Finepix F11				x				x				x		
Fujifilm	Finepix F20				x				x				x		
Fujifilm	Finepix F30				x				x				x		
Fujifilm	Finepix F31 FD				x				x				x		
Fujifilm	Finepix F440	x							x				x		
Fujifilm	Finepix F450 zoom	x							x				x		
Fujifilm	Finepix F455	x							x				x		
Fujifilm	Finepix F460	x							x				x		
Fujifilm	Finepix F470	x							x			x			
Fujifilm	Finepix F650					x				x			x		



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Fujifilm	Finepix F810					x				x			x		
Fujifilm	Finepix S2 Pro														
Fujifilm	Finepix S3500 zoom														
Fujifilm	Finepix S5000														
Fujifilm	Finepix S5200 zoom														
Fujifilm	Finepix S5500														
Fujifilm	Finepix S5600														
Fujifilm	Finepix S610					x				x					x
Fujifilm	Finepix S6500 FD														
Fujifilm	Finepix S9600														
Fujifilm	Finepix V10				x				x				x		
Fujifilm	Finepix Z1		x						x		x				
Fujifilm	Finepix Z2 zoom		x						x		x				
HP	Photosmart 935														
HP	Photosmart 945														
HP	Photosmart E317			x					x				x		
HP	Photosmart E327			x					x					x	
HP	Photosmart M22			x					x				x		
HP	Photosmart M23				x				x				x		
HP	Photosmart M407					x				x					
HP	Photosmart M417														
HP	Photosmart M425				x				x					x	
HP	Photosmart M517					x			x					x	
HP	Photosmart M525					x			x					x	
HP	Photosmart M527			x					x						x
HP	Photosmart R507			x					x				x		
HP	Photosmart R607			x					x				x		
HP	Photosmart R707					x			x						x
HP	Photosmart R717					x			x						x
HP	Photosmart R725				x				x		x				
HP	Photosmart R727				x				x		x				



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
HP	Photosmart R817				x				x				x		
HP	Photosmart R818				x				x				x		
HP	Photosmart R827				x				x				x		
HP	Photosmart R927				x				x				x		
HP	Photosmart R967				x				x				x		
Kodak	DCS-14n														
Kodak	Easyshare C310					x								x	
Kodak	Easyshare C330					x								x	
Kodak	Easyshare C340					x								x	
Kodak	Easyshare C360					x				x					
Kodak	Easyshare C433					x				x			x		
Kodak	Easyshare C530				x				x				x		
Kodak	Easyshare C533					x				x				x	
Kodak	Easyshare C643					x				x				x	
Kodak	Easyshare C663					x				x				x	
Kodak	Easyshare C743					x							x		
Kodak	Easyshare C875					x				x				x	
Kodak	Easyshare CX 7430					x				x					
Kodak	Easyshare CX 7525					x				x					
Kodak	Easyshare CX 7530					x				x					
Kodak	Easyshare DX4530														
Kodak	Easyshare DX6440					x				x					
Kodak	Easyshare DX7440					x				x					
Kodak	Easyshare DX7590														
Kodak	Easyshare DX7630					x									
Kodak	Easyshare LS 743					x				x					
Kodak	Easyshare LS 753					x				x			x		
Kodak	Easyshare LS443					x									
Kodak	Easyshare LS755				x					x			x		
Kodak	Easyshare P712														
Kodak	Easyshare P850														



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Kodak	Easysshare P880														
Kodak	Easysshare V530		x				x				x				
Kodak	Easysshare V550		x					x				x			
Kodak	Easysshare V570		x					x				x			
Kodak	Easysshare V603		x				x				x				
Kodak	Easysshare V610			x				x			x				
Kodak	Easysshare V705			x				x			x				
Kodak	Easysshare Z612														
Kodak	Easysshare Z650														
Kodak	Easysshare Z700														
Kodak	Easysshare Z730					x									
Kodak	Easysshare Z740														
Kodak	Easysshare Z760					x									
Kodak	Easysshare-one					x		x			x				
Konica	Digimax Z20														
Konica	Dimage 7Hi														
Konica	Dimage 7i														
Konica	Dimage A1														
Konica	Dimage F300					x		x				x			
Konica	Dimage G500					x		x				x			
Konica	Dimage G600					x		x				x			
Konica	Dimage KD500					x		x				x			
Konica	Dimage KD510					x		x				x			
Konica	Minolta Dimage A2														
Konica	Minolta Dimage A200														
Konica	Minolta Dimage E500				x			x					x		
Konica	Minolta Dimage X1					x		x					x		
Konica	Minolta Dimage X50				x			x			x				
Konica	Minolta Dimage X60				x			x			x				
Konica	Minolta Dimage Z10														
Konica	Minolta Dimage Z3														



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Konica	Minolta Dimage Z5														
Konica	Minolta Dimage Z6														
Konica	Minolta Dynax 5D														
Nikon	Coolpix 4100					x				x					
Nikon	Coolpix 4200					x				x					
Nikon	Coolpix 4300														
Nikon	Coolpix 4600					x				x			x		
Nikon	Coolpix 4800														
Nikon	Coolpix 5200					x			x					x	
Nikon	Coolpix 5400														
Nikon	Coolpix 5600					x			x				x		
Nikon	Coolpix 5700														
Nikon	Coolpix 5900					x				x				x	
Nikon	Coolpix 7600					x				x				x	
Nikon	Coolpix 7900					x				x				x	
Nikon	Coolpix 8400														
Nikon	Coolpix 8700														
Nikon	Coolpix L1/L101					x									
Nikon	Coolpix L2				x				x				x		
Nikon	Coolpix L3				x				x				x		
Nikon	Coolpix L4					x				x			x		
Nikon	Coolpix L5					x				x					
Nikon	Coolpix L6				x				x			x			
Nikon	Coolpix P1					x				x				x	
Nikon	Coolpix P2					x				x				x	
Nikon	Coolpix P3				x					x			x		
Nikon	Coolpix P4				x					x			x		
Nikon	Coolpix S1	x								x		x			
Nikon	Coolpix S10														
Nikon	Coolpix S2	x								x		x			
Nikon	Coolpix S3	x								x		x			



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Nikon	Coolpix S4					x									
Nikon	Coolpix S5	x						x		x					
Nikon	Coolpix S6			x				x		x					
Nikon	Coolpix S7c			x				x		x					
Nikon	Coolpix S9	x						x		x					
Nikon	D80														
Olympus	AZ-2 zoom				x			x				x			
Olympus	C170					x								x	
Olympus	C50 zoom					x			x						
Olympus	C5000 zoom														
Olympus	C-5050 zoom														
Olympus	C5060 zoom														
Olympus	C5500														
Olympus	C60					x			x						
Olympus	C7000					x			x						
Olympus	C8080 widezoom														
Olympus	Camedia C180					x		x						x	
Olympus	Camedia C70 zoom					x									
Olympus	E-20														
Olympus	E-400														
Olympus	E500														
Olympus	FE-100					x			x						
Olympus	FE-110					x			x						x
Olympus	FE-115					x			x						x
Olympus	FE-120					x			x					x	
Olympus	FE-130				x			x			x				
Olympus	FE-150	x						x			x				
Olympus	FE-160	x						x			x				
Olympus	FE-170				x				x				x		
Olympus	FE-180			x				x					x		
Olympus	FE-190	x						x			x				



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Olympus	FE-200				x			x				x			
Olympus	mju digital 1000			x				x		x					
Olympus	mju Digital 400					x			x				x		
Olympus	mju Digital 410					x			x						
Olympus	mju Digital 500					x		x				x			
Olympus	mju Digital 600				x			x				x			
Olympus	mju digital 700			x				x		x					
Olympus	mju digital 710SW			x				x		x					
Olympus	mju digital 720SW			x				x		x					
Olympus	mju digital 725SW			x				x		x					
Olympus	mju digital 730			x				x		x					
Olympus	mju digital 740		x					x			x				
Olympus	mju digital 750		x					x			x				
Olympus	mju digital 800					x			x				x		
Olympus	mju digital 810				x			x			x				
Olympus	mju Mini Digital				x				x			x			
Olympus	mju Mini Digital S				x				x			x			
Olympus	Olympus C315 zoom					x				x				x	
Olympus	Olympus C55 zoom					x									
Olympus	Olympus FE-140					x			x			x			
Olympus	Olympus IR 300		x					x			x				
Olympus	SP 310					x				x				x	
Olympus	SP 320					x				x				x	
Olympus	SP 350					x				x				x	
Olympus	SP 500														
Olympus	SP 510 UZ														
Olympus	SP 700				x				x			x			
Panasonic	DMC-FX01		x					x			x				
Panasonic	DMC-FX01K		x					x			x				
Panasonic	DMC-FX01P		x					x			x				
Panasonic	DMC-FX01S		x					x			x				



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Panasonic	DMC-FX01W		x				x			x					
Panasonic	DMC-FX07		x				x			x					
Panasonic	DMC-FX2		x				x			x					
Panasonic	DMC-FX3		x				x			x					
Panasonic	DMC-FX5														
Panasonic	DMC-FX50				x			x			x				
Panasonic	DMC-FX7		x				x			x					
Panasonic	DMC-FX7K		x				x			x					
Panasonic	DMC-FX8		x				x			x					
Panasonic	DMC-FX8K		x				x			x					
Panasonic	DMC-FX8S		x				x			x					
Panasonic	DMC-FX9		x				x			x					
Panasonic	DMC-FX9K		x				x			x					
Panasonic	DMC-FX9S		x				x			x					
Panasonic	DMC-FZ10														
Panasonic	DMC-FZ4S														
Panasonic	DMC-FZ5														
Panasonic	DMC-FZ50														
Panasonic	DMC-FZ5K														
Panasonic	DMC-FZ5S														
Panasonic	DMC-FZ7K														
Panasonic	DMC-FZ7S														
Panasonic	DMC-L1														
Panasonic	DMC-LC43					x				x				x	
Panasonic	DMC-LC70					x				x				x	
Panasonic	DMC-LC80					x				x				x	
Panasonic	DMC-LS1				x				x				x		
Panasonic	DMC-LS2S			x						x			x		
Panasonic	DMC-LS3			x				x					x		
Panasonic	DMC-LX1K			x				x				x			
Panasonic	DMC-LX1S			x				x				x			



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Panasonic	DMC-LX2			x				x			x				
Panasonic	DMC-LZ1					x		x				x			
Panasonic	DMC-LZ2					x		x				x			
Panasonic	DMC-LZ3S					x									
Panasonic	DMC-LZ5K					x									
Panasonic	DMC-LZ5S					x									
Panasonic	DMC-TZ1K					x									
Panasonic	DMC-TZ1S					x									
Panasonic	Lumix DMC-LZ4														
Pentax	ist D														
Pentax	ist DL														
Pentax	ist DS														
Pentax	ist DS Silver														
Pentax	K10D														
Pentax	K110D														
Pentax	Optio 50				x			x				x			
Pentax	Optio 50L					x		x				x			
Pentax	Optio 550					x			x						
Pentax	Optio 555					x			x						
Pentax	Optio 60					x		x							
Pentax	Optio 750Z					x									
Pentax	Optio A10			x				x			x				
Pentax	Optio A20			x				x			x				
Pentax	Optio E10				x			x					x		
Pentax	Optio E20				x			x					x		
Pentax	Optio M10				x			x			x				
Pentax	Optio M20				x			x			x				
Pentax	Optio MX4														
Pentax	Optio S4	x						x			x				
Pentax	Optio S40				x			x			x				
Pentax	Optio S45				x			x			x				



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Pentax	Optio S4i	x					x			x					
Pentax	Optio S50				x			x			x				
Pentax	Optio S55				x			x				x			
Pentax	Optio S5i	x					x			x					
Pentax	Optio S5n	x					x			x					
Pentax	Optio S5z	x					x			x					
Pentax	Optio S6	x					x			x					
Pentax	Optio S60				x			x				x			
Pentax	Optio S7	x					x			x					
Pentax	Optio SV				x			x				x			
Pentax	Optio SVi				x			x				x			
Pentax	Optio T10	x						x			x				
Pentax	Optio T20	x						x			x				
Pentax	Optio W10			x			x				x				
Pentax	Optio W20			x			x				x				
Pentax	Optio WP			x			x				x				
Pentax	Optio Wpi			x			x				x				
Pentax	Optio X			x			x				x				
Samsung	Digimax 401			x				x							
Samsung	Digimax 530					x			x						
Samsung	Digimax A40			x					x			x			
Samsung	Digimax A402				x		x					x			
Samsung	Digimax A5					x		x					x		
Samsung	Digimax A50			x				x			x				
Samsung	Digimax A502			x			x				x				
Samsung	Digimax A503			x				x				x			
Samsung	Digimax A55W			x				x			x				
Samsung	Digimax A6					x		x					x		
Samsung	Digimax A7					x		x					x		
Samsung	Digimax GX-10														
Samsung	Digimax i5	x						x		x					



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Samsung	Digimax i50	x						x		x					
Samsung	Digimax i6	x						x		x					
Samsung	Digimax L50	x					x			x					
Samsung	Digimax L55W			x			x					x			
Samsung	Digimax L60	x					x			x					
Samsung	Digimax L70	x						x		x					
Samsung	Digimax L85					x			x			x			
Samsung	Digimax S500					x			x			x			
Samsung	Digimax S600				x			x			x				
Samsung	Digimax S800				x			x				x			
Samsung	Digimax U-CA 505	x					x				x				
Samsung	Digimax U-CA4					x		x				x			
Samsung	Digimax U-CA5					x		x				x			
Samsung	Digimax V5					x			x						
Samsung	Digimax V50					x			x						
Samsung	Digimax V6					x			x						
Samsung	Digimax V700			x				x				x			
Samsung	Digimax V800			x				x				x			
Samsung	NV10	x						x		x					
Samsung	NV3	x						x		x					
Samsung	NV7 OPS				x			x		x					
Samsung	S1000				x			x				x			
Samsung	S700				x			x			x				
Sanyo	Xacti E60				x			x		x					
Sanyo	Xacti HD 1A														
Sanyo	Xacti HD 1EX														
Sanyo	Xacti S60				x			x		x					
Sanyo	Xacti VPC-C40					x			x				x		
Sanyo	Xacti VPC-C5					x			x			x			
Sanyo	Xacti VPC-C6					x			x			x			
Sanyo	Xacti VPC-CA6 Active														



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Sanyo	Xacti VPC-E6				x			x		x					
Sanyo	Xacti VPC-E7			x				x		x					
Sanyo	Xacti VPC-J4			x				x			x				
Sanyo	Xacti VPC-S4				x			x				x			
Sanyo	Xacti VPC-S5				x			x				x			
Sanyo	Xacti VPC-S6			x			x					x			
Sanyo	Xacti VPC-S7	x						x			x				
Sony	DSC-S40					x		x						x	
Sony	DSC-S60					x									
Sony	DSC-S600					x		x				x			
Sony	DSC-S80					x									
Sony	DSC-F707														
Sony	DSC-F717														
Sony	DSC-F77					x				x				x	
Sony	DSC-F828														
Sony	DSC-F88					x				x				x	
Sony	DSC-FD200														
Sony	DSC-FX77					x				x				x	
Sony	DSC-H1														
Sony	DSC-L1				x		x				x				
Sony	DSC-M1			x								x			
Sony	DSC-M2											x			
Sony	DSC-N1			x				x				x			
Sony	DSC-N2			x				x				x			
Sony	DSC-P10					x		x						x	
Sony	DSC-P100			x				x				x			
Sony	DSC-P12					x		x						x	
Sony	DSC-P120			x				x				x			
Sony	DSC-P150			x				x				x			
Sony	DSC-P2					x								x	
Sony	DSC-P200					x		x				x			



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Sony	DSC-P200R					x		x					x		
Sony	DSC-P32					x			x					x	
Sony	DSC-P41					x			x					x	
Sony	DSC-P43					x			x					x	
Sony	DSC-P5					x			x					x	
Sony	DSC-P52														
Sony	DSC-P72														
Sony	DSC-P73													x	
Sony	DSC-P8					x			x					x	
Sony	DSC-P9					x								x	
Sony	DSC-P92														
Sony	DSC-P93					x								x	
Sony	DSC-P93A					x								x	
Sony	DSC-S500				x				x				x		
Sony	DSC-S85														
Sony	DSC-S90					x									
Sony	DSC-ST80					x				x					
Sony	DSC-T1				x				x		x				
Sony	DSC-T10	x						x			x				
Sony	DSC-T11				x				x		x				
Sony	DSC-T3	x							x		x				
Sony	DSC-T33	x							x		x				
Sony	DSC-T5				x				x		x				
Sony	DSC-T50	x							x			x			
Sony	DSC-T5B	x							x			x			
Sony	DSC-T7	x							x		x				
Sony	DSC-T9	x							x		x				
Sony	DSC-U20		x				x						x		
Sony	DSC-U30		x				x						x		
Sony	DSC-U40		x				x					x			
Sony	DSC-U50		x				x							x	



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Sony	DSC-U60														
Sony	DSC-V1														
Sony	DSC-V3														
Sony	DSC-W1					x			x						
Sony	DSC-W100				x			x			x				
Sony	DSC-W12					x		x							
Sony	DSC-W15					x		x							
Sony	DSC-W17					x		x							x
Sony	DSC-W30				x			x		x					
Sony	DSC-W5					x		x							x
Sony	DSC-W50				x			x		x					
Sony	DSC-W7					x			x						x
Sony	DSC-W70				x			x		x					
Fujifilm	Finepix S5 Pro														
Kodak	Easyshare Z710														
Ricoh	Caplio R5			x				x				x			
Ricoh	GR Digital			x				x				x			
Ricoh	Caplio GX8					x			x					x	
Ricoh	Caplio R4			x				x			x				
Ricoh	Caplio R40			x				x			x				
Ricoh	Caplio R3			x				x			x				
Ricoh	Caplio RR630				x			x						x	
Ricoh	Caplio RR660	x						x						x	
Acer	CE-5430	x						x					x		
Acer	CE-5330				x			x							x
Acer	CI-6330				x			x							x
Acer	CE-6430				x			x						x	
Acer	CS-5531	x						x			x				
Acer	CI-8330					x			x						x
Acer	CS-6530	x						x				x			
Acer	CS-6531	x							x			x			



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Acer	CR-8530			x				x				x			
Acer	CU-6530	x					x			x					
Acer	CP-8531	x						x				x			
Acer	CP-8660				x			x						x	
Praktica	DC50			x				x				x			
Praktica	DC-Z5.8	x						x				x			
Praktica	DC-Z6.2					x			x						
Praktica	DC60			x				x				x			
Praktica	DC-Z5.5					x			x					x	
Praktica	Luxmedia 5203				x			x						x	
Praktica	Luxmedia 6203				x			x						x	
Praktica	DC-Z5.4					x									
Praktica	Luxmedia 5303			x			x				x				
Praktica	DC-Z7.1				x			x				x			
Praktica	Luxmedia 6403														
Praktica	Luxmedia 6503	x						x			x				
Praktica	Luxmedia 6105			x				x			x				
Rollei	dp6500				x			x						x	
Rollei	da10	x					x			x					
Rollei	db60	x						x				x			
Rollei	da5324				x			x						x	
Rollei	dp8300				x			x				x			
Rollei	dp6200	x						x			x				
Rollei	da6324				x			x						x	
Rollei	Prego dp5200	x						x		x					
Rollei	ds6	x					x			x					
Rollei	dx63				x			x				x			
Rollei	dt6 tribute			x				x				x			
Leica	C-Lux1	x						x		x					
Leica	Digilux 3														
Leica	D-Lux3			x				x						x	



**ORGANISED  
CHAOS™**

# SIZE MATTERS

## Camera fitting list

Version 20/12/2006

		P.P.					Glamour P.P.				Checker				
		40	45	55	70	90	50	65	70	90	65	70	90	100	120
Leica	M8														
Leica	V-Lux1														
Ricoh	Caplio RR730			x				x			x				
Nikon	D40														
Ricoh	Caplio 500G wide														
Ricoh	Caplio R30				x			x			x				
Ricoh	Caplio RR530				x			x				x			
Ricoh	Caplio R2			x				x				x			
Ricoh	Caplio R1V			x				x				x			
HP	Photosmart R627				x			x				x			
HP	Photosmart E427				x			x			x				
Samsung	Digimax L80					x		x				x			